

# MEEXE

A BIG U-TURN IN DECORATIVE COATINGS

## READYGO!

STEP BY STEP

01

### CLEAN THE SURFACE TO BE COATED

For an optimum result, it is essential that the surface is free of dust and grease.

After cleaning, take the protective masking tape and mark out the area to be coated.

\*Important: if the substrate is not stable and/or has cracks or flaking, repair it. If there is excessive moisture in the substrate, address it first.



02

### ABSORBENT / NON-ABSORBENT SURFACES

It's time to prepare the surface so the microcement bonds properly. For that, we use **Meexe Primer 300**.

Use a spatula to manually stir the product. Take the roller and apply one coat of **Meexe Primer 300**. Wait 1 hour for it to dry and clean the roller with water immediately after use to extend its lifespan.

\*Important: On surfaces with joints, fill them beforehand with a joint-filling putty.



03

### APPLY MEEXE READYGO! 03

Stir **Meexe ReadyGo! 03** with the help of a spatula. Then, wet the microcement roller with **Meexe ReadyGo! 03**, paint a section of the surface and immediately go over it with the trowel.

Apply 2 coats using the roller and the trowel, and remove the masking tape. Leave 6 hours between coats so it dries properly.

Sand after each coat with 40-grit sandpaper.



04

### APPLY MEEXE READYGO! 01

Apply the protective masking tape again. Wet the microcement roller with **Meexe ReadyGo! 01**, paint a section of the wall and immediately go over it with the trowel.

Apply 2 coats using the roller and the trowel.

Remove the tape and leave 6 hours of drying time between coats. Sand after each coat with 220-grit sandpaper.



05

### APPLY THE VARNISH

Choose the finish (matte or satin) of **Meexe SealantGo!**, which will protect the surfaces so they look perfect.

24 hours after applying the last coat of **Meexe ReadyGo! 01**, place masking tape on the surface. Apply 3 coats of **Meexe SealantGo!** in the same day, allowing 4 hours of drying time between coats.

We recommend sanding the first and second coat with 400-grit sandpaper.

\*Important: We recommend waiting 7 days for the varnish to reach its maximum performance.

\*\*All sandpaper grits indicated in this step-by-step are for manual sanding (not machine sanding).



### ICON GUIDE



Trowel

Roller

Sanding disc

Masking tape